

INSTRUCTIONS

8 Cu. Ft. Landscape Double Wheel Barrows

Before assembling your Bon Tool Co. Double Wheel Landscape Wheelbarrow, please make sure you have the following items. NOTE: The wheelbarrow comes with ONE pair of handles: steel or wood.

FOR MORE PARTS LIST INFORMATION (REFER TO PART LIST PL28966)

REF #	KEY #	PART #	DETAIL	QTY/UNIT
28-966	001	50-197	Poly Tray	1
28-966	002	50-532	Steel Handles (pr)	1
28-966	002	50-244	Wood Handles (pr)	1
28-966	003	50-319	Rear Support	1
28-966	004	50-320	Leg	2
28-966	005	50-321	Leg Brace	1
28-966	006	50-323	Wedge	2
28-966	007	50-324	Front Support	1
28-966	008	50-344	Vertical Tray Brace	2
28-966	009	50-174	Rim & Tire (Knobby)	2
28-966	009	84-714	Rim & Tire (Flat Free)	2
28-966	009	80-105	Rim & Tire (Ribbed)	2
28-966	010	50-326	Nose Piece	1
28-966	011	50-247	24" Axle	1
28-966	013	50-332	Axle Bracket (Dbl Wheel Only)	2
28-966	n/a	52-435	Carriage Bolt 5/16" x 5"	2
28-966	n/a	52-434	Carriage Bolt 5/16" x 3 3/4"	2
28-966	n/a	52-433	Carriage Bolt 5/16" x 2 1/2"	4
28-966	n/a	52-401	Carriage Bolt 5/16" x 2 1/4"	4
28-966	n/a	52-438	Carriage Bolt 5/16" x 1"	8
28-966	n/a	52-201	Nut 5/16"	20
28-966	n/a	52-127	Lock Washer	20
28-966	n/a	52-670	Cotter Pin	2
28-966	n/a	52-108	Washer 5/8" x 1-3/4"	2
28-966	022	50-328	Leg Stabilizer	2
28-966	n/a	80-102	Innertube	2
28-966	n/a	80-101	Bearings (pr)	2

ASSEMBLING THE TRAY, HANDLES & LEGS

Place the poly tray upside down. Place one wedge (key #006) on the tray with the large end of the wedge facing towards the front of the tray. Place one of the handles (key 002) on top of the wedge (Note which way the handle is coming off of the tray, so as to not attach the handles the wrong way). Matching up the hole at the back end of the tray, wedge, and handle place the rear support on top of those items. Finally, place one of the legs (key #004) on top of the rear support with the holes on the legs facing the back of the tray. Matching up the holes, place 3-3/4" carriage bolt in through the tray and then finger tighten one of the 5/16" nuts onto the carriage bolt. Place the front support (key #007) underneath the leg and put a 5" carriage bolt through the tray, wedge, handle, front support, and leg. Finger tighten a 5/16" nut onto the carriage bolt, and do the same thing for the other side.



Attach the leg brace (key #005) by inserting it between the legs using the 1" carriage bolts and 5/16" nuts. While attaching the leg brace place the stabilizer (key #022) to the leg (key #004) and fasten with 1" carriage bolt.

ASSEMBLING THE AXLE ASSEMBLY

Place the Axle Bracket (key #013) on the Wood Handle. Attach the Vertical Tray Brace (key #008) to the Tray using the two 1" carriage bolts. Next, use the 2-1/2" carriage bolt and put it through the Vertical Tray Brace, and the Axle Bracket. Finger tighten one of the 5/16" nuts on the carriage bolt, and complete the above process on the other side of the wheelbarrow. After completing this on the other side, put the 24" Axle (key #011) through the Axle Bracket on both sides. Use the other two 2-1/2" carriage bolts and 5/16" nuts and finish attaching the axle brackets.

To attach the tires, place one of the lock washers on each side of the axle. Next, place each Wheel (key #009) on the axle. Place the other washers onto each side of the axle and put in the Cotter Pins, through the holes in the axle.

Attach the nose piece (key #010) by using the 2-1/4" Carriage Bolts and 5/16" nuts. Finally, finish your assembly by tightening all of the nuts using a 1/2" wrench and 1/2" socket.

MAINTENANCE

Periodically, grease the fitting on the tires. Keep clean from debris after use.